

# ETHAN ALLEN®

## Caira Floor Lamp Assembly Instructions 09-2018 BRS

### IMPORTANT SAFETY INSTRUCTIONS

TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, AND PERSONAL INJURY:

This lighting fixture is for indoor use only. This lamp is equipped with a polarized plug. One plug blade is wider than the other. DO NOT MODIFY the plug or power cord in any way. DO NOT EXCEED the recommended bulb wattage. Use only the type of bulb specified. Keep flammable materials away from the bulb. DO NOT OPEN the product or alter the wiring in any manner. If using an extension cord, follow precautions provided with the power cord. Use care when unpacking.

Use care when unpacking. Locate ALL THE PARTS INCLUDED before disposing of packaging materials. Remove the silica gel packet from the socket before plugging the lamp into an outlet.

### ASSEMBLY, CARE, AND TROUBLESHOOTING

- No tools are required for assembly
- Light bulb is not included

#### Parts Included: (Refer to Figure)

- A. Finial
- B. Shade
- C. Harp
- D. Socket
- E. Saddle
- F. Plug Cover

#### Assembly Procedure: (Refer to the Figure)


1. Insert the Harp (C) into the Saddle (E).
2. Install Shade (B) onto Harp (C).
3. Install Finial (A) into Harp (C).
4. Install bulb (E26 Type A 100W) into Socket (D).
5. Remove Plug Cover (F) from Plug.

#### Caring for and cleaning your lamp:

1. Wipe with a soft dry cloth.
2. Avoid cleaners, scouring pads, etc.
3. Before changing bulb(s), unplug lamp and allow the bulb to cool.

#### Troubleshooting:

Problem:	Possible cause:	Correction:
Bulb does not light	Bulb is burnt out or damaged	Replace bulb
	Power to lamp is off	Confirm power is on
	Lamp is not plugged in	Confirm lamp is plugged in



If the fixture still does not work after troubleshooting, please contact your local Ethan Allen Design Center.

SAVE THESE INSTRUCTIONS