

ETHAN ALLEN®

09-6861B MARGEUX TABLE LAMP

TABLE AND FLOOR LAMP SAFETY, ASSEMBLY, CARE, AND TROUBLESHOOTING

IMPORTANT SAFETY INSTRUCTIONS

TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, AND PERSONAL INJURY:

This lighting fixture is for indoor use only. This lamp is equipped with a polarized plug. One plug blade is wider than the other. DO NOT MODIFY the plug or power cord in any way. DO NOT EXCEED the recommended bulb wattage. Use only the type of bulb specified. Keep flammable materials away from bulb. DO NOT OPEN the product or alter the wiring in any manner. Extension cord: Follow precautions provided with power cord.

UNPACKING:

Use care when unpacking. Locate ALL PARTS INCLUDED before disposing of packaging materials.

ASSEMBLY, CARE, AND TROUBLESHOOTING

Tools Required For Assembly: Tools are not required.
Required: Light bulb is not included.

Parts Included: Refer to Figure 1.

- A. Harp: *Harp styles may vary.*
- B. Lamp Base.
- C. Shade: *Shade may be packed in separate carton.*
- D. Shade Finial.
- E. Lamp Socket (*attached, no assembly required*).
- F. Line Cord Plug.

Assembly Procedure: Refer to Figure 1.


1. Install Harp Part A onto Lamp Base Part B.
2. Install Shade Part C onto Harp Part A.
3. Install Shade Finial Part D onto Harp Part A.
4. Install Bulb into Lamp Socket Part E.
5. Remove Plug Cap, Part F from Plug.

Caring for and Cleaning your lamp:

1. To clean, wipe with a soft, dry cloth.
2. DO NOT USE cleaners, scouring pads, etc.
3. Unplug lamp and allow bulb to cool before changing bulb.

Troubleshooting:

Problem	Possible cause:	Correct by:
Bulb does not light	Bulb is burnt out or damaged	Replace bulb
	Power to lamp is off	Confirm power is on
	Lamp is not plugged in	Confirm lamp is plugged in



In the event that the lighting fixture does not work after troubleshooting, contact your local Ethan Allen Design Center.

SAVE THESE INSTRUCTIONS

ETHAN ALLEN®

09-6861B MARGEAUX TABLE LAMP, TABLEAU DES FEUX ET SÉCURITÉ AU SOL, ENSEMBLE, PRÉCAUTIONS ET ÉCHECS.

MESURES DE SÉCURITÉ IMPORTANTES

POUR RÉDUIRE LE RISQUE D'INCENDIE, DE CHOCS ET DE BLESSURES:

Ce luminaire est pour usage interne uniquement. Cette lampe est équipée d'une prise polarisée. Une lame de bouchon est plus grande que l'autre. NE PAS MODIFIER la fiche ou le cordon d'alimentation de quelque façon. NE PAS DÉPASSER la capacité recommandée de l'ampoule. Utilisez uniquement le type spécifié de la lampe. Gardez les matériaux inflammables loin de l'ampoule. NE PAS OUVRIR le produit ou changer le câblage en aucune façon. Extension: Suivez la prudence fournie avec le cordon d'alimentation.

DÉBALLAGE:

Soyez prudent lors du déballage. Repérez TOUTES LES PARTIES présentes avant l'élimination des matériaux d'emballage.

ENSEMBLE, SOINS ET SHOOTING

Outils requis pour l'assemblage: les outils ne sont pas nécessaires.

Requis: l'ampoule n'est pas incluse.

Composants inclus: Se reporter à la fig. 1.

- A. Harpe: *les styles peuvent varier.*
- B. Pied de lampe
- C. Abat-jour: *L'abat-jour peut être emballé dans une boîte séparée.*
- D. Épi de faitage (*pour visser l'araignée de l'abat-jour sur la harpe*).
- E. La douille .
- F. Câblage avec prise.

Procédure de montage: Se reporter à la figure 1.


1. Installer la harpe fig.A sur la lampe fig.B.
2. Installer l'abat-jour fig.C sur la harpe fig.A.
3. Installer l'épi de faitage fig.D sur la harpe fig.A.
4. Installer l'ampoule dans la douille fig.E.
5. Retirez le capuchon de protection de la prise fig. F.

Entretien et nettoyage de la lampe:

1. Nettoyer avec un chiffon doux et sec.
2. NE PAS UTILISER de détergent, de tampons à récurer, etc.
3. Débranchez la lampe et laissez l'ampoule refroidir avant de la remplacer.

Dépannage:

Problème	Cause possible:	Solution:
L'ampoule ne s'allume pas	L'ampoule est brûlée ou endommagée	Changer l'ampoule
	L'alimentation de la lampe est éteinte	Vérifiez la puissance
	La lampe n'est pas branché	Confirmation que la lampe est connecté



Dans le cas où l'appareil d'éclairage ne fonctionne pas après le dépannage, contactez votre Ethan Allen distributeur local.

CONSERVER CES INSTRUCTIONS